
# QW-NS1CF49EW-EU



# Highligths

- 10 Place Settings
- 2 Racks
- 4 Programmes
- E Energy Efficiency
- Freestanding 45cm
- Quick 30'
- Active Drying
- 11 L Water Consumption





Program your dishwasher so that it starts at a time that suits you.



Keep your children safe from accidentally using the microwave with the easy to set up Child Lock.









Máis características



### Key Features

Energy Efficiency Ε Quick Wash Duration (mins) Quick 30' Number of Programs Colour White Cleaning Performance Drying Performance Number of Place Settings 10 Number of racks 2 Dishwasher Type Dishwasher Type WaterBlade & AquaGlide N/A

Active

11

#### Other features

Water Consumption (L)

Drying System

Extra Silent Option

N/A

Extra Fast Option

N/A

IntelliWash

N/A

Built-in Appliance

N/A

Advanced Inverter Motor

N/A

Graphic Displays Si AutoDoor N/A EcoBox N/A MicroBan Si Height Adjustable Upper Basket Si Number of Mug Shelves 4 Fixed Mugshelves Foldable Racks on Upper Basket Foldable Racks on Lower Basket Si Child Lock(Other Features) Si Aquastop N/A EcoWash Si Hygiene Wash N/A Express 50 Si Thirty Minute Wash Delay Timer Si Super Quiet N/A Interior LED Lighting N/A Overflow and Leakage Protection Si EasyTray N/A

Extra Hygiene Option



N/A

Extra Dry Option	N/A
Half Load Option	Si
Number of Spray Arms	2
Washing Cycle Indicator	Si
Water Inlet	Cold
Noise Level (dB(A) re1 pW)	49
Adjustable Feet	Si
Rinse-Aid Indicator	Si
Salt Indicator	Si
Removable Cutlery Basket	Si
DualProWash	N/A

Dimensions	and	Weight

85,0x45,0x59,8
89,1x49,4x66,1
40
42

## Programmes

Programme 1	Quick 30'
-------------	-----------

Programme 2	Eco 50°C
Programme 3	Express 50'
Programme 4	Intensive 65°C

### Code EAN

EAN Code 4974019168708

# Power, consumption, and voltage

	$\sim$
Electrical Current (A)	10
Voltage / Frequency (V) / (Hz)	220-240 / 50
Annual Energy Consumption (Kwh)	211
Annual Water Consumption (L)	3080

## Power, Consumption&Voltage

Water Consumption (L)

