QW-NA1BF47ES-EU



Highligths

- 13 Place Settings
- 2 Racks
- 3 Progammes
- E Energy Efficiency
- Freestanding 60cm
- Express 50'
- Active Drying
- 12 L Water Consumption





Program your dishwasher so that it starts at a time that suits you.



Keep your children safe from accidentally using the microwave with the easy to set up Child Lock.



For those times when you only have half a load but need it done the Eco Wash allows you to select either the top or bottom half of the machine to be cleaned.



When time is of the essence this program does the dishes in 50 minutes at 60°c.



When you have to fit every dish, glass, fork and pot into one load these machines can cater to even the largest of families or dinner parties.



Sharp machines like to keep you informed of everything that is going on within them with an easy-to-read set of displays.

More Features



Key Features

Energy Efficiency E

Quick Wash Duration (mins) Express 50'

Number of Programmes

Colour Dark Silver

Cleaning Performance

Drying Performance

Number of Place Settings

Number of racks

Number of Racks

Dishwasher Type Freestanding 60cm

WaterBlade & AquaGlide N/A

Drying System Active

Water Consumption (L) 12

Other features

Child Lock Yes
Washing Cycle Indicator Yes

Water Inlet Cold

Foldable Racks on Upper Basket N/A

Foldable Racks on Lower Basket N/A

Number of Spray Arms 2

Extra Silent Option N/A

Extra Fast Option N/A

IntelliWash N/A

Built-in Appliance N/A

Advanced Inverter Motor N/A

Graphic Displays Yes

AutoDoor N/A

EcoBox N/A

MicroBan Yes

Height Adjustable Upper Basket Yes

Number of Mug Shelves 4 Adjustable Mugshelves

DualProWash N/A

Aquastop N/A

EcoWash Yes

Hygiene Wash N/A

Express 50 Yes

Thirty Minute Wash

Thirty Minute Wash

Delay Timer Yes

Super Quiet N/A

Interior LED Lighting N/A Overflow and Leakage Protection Yes EasyTray N/A Extra Hygiene Option N/A Extra Dry Option N/A Half Load Option Yes Noise Level (dB(A) re1 pW) 47 Adjustable Feet Yes Rinse-Aid Indicator Yes Salt Indicator Yes Removable Cutlery Basket Yes

Dimensions and Weight

Packing Dimensions (WxDxH) (mm) 88,1x64,4x66,1

Unpacked Dimensions (HxWxD) (mm) 85,0x59,8x59,8

Product Weight Unboxed (net)(kg) Product Weight Unboxed

(net)

Product Weight Boxed (gross)(kg) 49

Power, Consumption, & Voltage

Electrical Current (A)

Voltage / Frequency (V) / (Hz) 220-240 / 50

Annual Energy Consumption (Kwh) 261

Annual Water Consumption (L) 3360

European Article Number

EAN Code 4974019168333

Programmes

Programme 1 Eco 50°C

Programme 2 Express 50'

Programme 3 Intensive 65°C

