## Full-size

# QW-NA1CF47EW-ES



## Highligths

- 13 Place Settings
- 2 Racks
- 4 Progammes
- E Energy Efficiency
- Freestanding 60cm
- Quick 30'
- Active Drying
- 12 L Water Consumption





Program your dishwasher so that it starts at a time that suits you.



Keep your children safe from accidentally using the microwave with the easy to set up Child Lock.



For those times when you only have half a load but need it done the Eco Wash allows you to select either the top or bottom half of the machine to be cleaned.



When time is of the essence this program does the dishes in 50 minutes at 60°c.



When you have to fit every dish, glass, fork and pot into one load these machines can cater to even the largest of families or dinner parties.



Sharp machines like to keep you informed of everything that is going on within them with an easy-to-read set of displays.

# More Features



#### Key Features

Energy Efficiency

Quick Wash Duration (mins)

Quick 30'

Number of Programmes

4

Colour

Colour

Cleaning Performance

A

Drying Performance

A

Number of Place Settings

13

Dishwasher Type Freestanding 60cm

2

WaterBlade & AquaGlide N/A

Drying System Active

Water Consumption (L) 12

#### Other features

Number of racks

Rinse-Aid Indicator

Yes

Salt Indicator

Yes

Extra Silent Option

N/A

Extra Fast Option

N/A

IntelliWash

N/A

Built-in Appliance N/A Advanced Inverter Motor N/A Graphic Displays Yes AutoDoor N/A EcoBox N/A MicroBan Yes Height Adjustable Upper Basket Yes Number of Mug Shelves 4 Adjustable Mugshelves Foldable Racks on Upper Basket Yes Foldable Racks on Lower Basket Yes DualProWash N/A Child Lock Yes Aquastop N/A EcoWash Yes Hygiene Wash N/A Express 50 Yes Thirty Minute Wash N/A Delay Timer Yes

Super Quiet

Interior LED Lighting



N/A

N/A

Overflow and Leakage Protection Yes EasyTray N/A Extra Hygiene Option N/A Extra Dry Option N/A Half Load Option Yes Number of Spray Arms Washing Cycle Indicator Water Inlet Cold Noise Level (dB(A) re1 pW) 47 Adjustable Feet Yes Rinse-Aid Indicator Yes Removable Cutlery Basket Yes

#### Dimensions and Weight

Product Weight Boxed 49

Product Weight Unboxed (net)(kg) 46

Unpacked Dimensions (HxWxD) (mm) 85,0x59,8x59,8

Packed Dimensions (shrink) (HxWxD) 88,1x64,4x66,1

#### European Article Number

EAN Code 4974019168364

#### Programmes

Programme 1 Eco 50°C

Programme 2 Express 50'

Programme 3 Intensive 65°C

Programme 4 Quick 30'

#### Power, Consumption&Voltage

Electrical Current (A)

Voltage / Frequency (V) / (Hz) 220-240 / 50

Annual Energy Consumption (Kwh) 261

Annual Water Consumption (L) 3360

