
QW-NS1CF49ES-EU



Highligths

- 10 Place Settings
- 2 Racks
- 4 Programmes
- E Energy Efficiency
- Freestanding 45cm
- Quick 30'
- Active Drying
- 11 L Water Consumption





Program your dishwasher so that it starts at a time that suits you.



Keep your children safe from accidentally using the microwave with the easy to set up Child Lock.



Space at home is often at a premium but these dishwashers are just 45cm wide and still take a total of 10 place settings.

Streamlined and efficient, the way technology should be.



For those times when you only have half a load but need it done the Eco Wash allows you to select either the top or bottom half of the machine to be cleaned.



When time is of the essence this program does the dishes in 50 minutes at 60°c.



Sharp machines like to keep you informed of everything that is going on within them with an easy-to-read set of displays.

More Features



Key Features

Energy Efficiency

Quick Wash Duration (mins)

Quick 30'

Number of Programmes

4

Colour

Dark Silver

Cleaning Performance

A

Drying Performance

A

Number of Place Settings 10

Number of racks 2

Dishwasher Type Freestanding 45cm

Active

WaterBlade & AquaGlide

N/A

Drying System

Water Consumption (L)

Other features

Extra Silent Option

N/A

Extra Fast Option

N/A

IntelliWash

N/A

Built-in Appliance

N/A

Advanced Inverter Motor

N/A

Graphic Displays Yes AutoDoor N/A EcoBox N/A MicroBan Yes Height Adjustable Upper Basket Yes Number of Mug Shelves 4 Fixed Mugshelves Foldable Racks on Upper Basket Yes Foldable Racks on Lower Basket Yes DualProWash N/A Child Lock Yes Aquastop N/A EcoWash Yes Hygiene Wash N/A Express 50 Yes Thirty Minute Wash Yes Delay Timer Yes Super Quiet N/A Interior LED Lighting N/A Overflow and Leakage Protection



Yes

N/A

EasyTray

Extra Hygiene Option N/A Extra Dry Option N/A Half Load Option Yes Number of Spray Arms 2 Washing Cycle Indicator Washing Cycle Indicator Water Inlet Cold Noise Level (dB(A) re1 pW) 49 Adjustable Feet Yes Rinse-Aid Indicator Yes Salt Indicator Yes Removable Cutlery Basket Yes

Dimensions and Weight

Unpacked Dimensions (HxWxD) (mm) 85,0x45,0x59,8

Packed Dimensions (shrink) (HxWxD) 89,1x49,4x66,1

Product Weight Unboxed (net)(kg) 40

Product Weight Boxed (gross)(kg) 42

Programmes

Programme 1 Quick 30'

Programme 2 Eco 50°C

Programme 3 Express 50'

Programme 4 Intensive 65°C

Code EAN

EAN Code 4974019168302

Power, consumption, and voltage

Electrical Current (A) 10

Voltage / Frequency (V) / (Hz) 220-240 / 50

Annual Energy Consumption (Kwh) 211

Annual Water Consumption (L) 3080

Power, Consumption&Voltage

Water Consumption (L)

