# QW-NS22F47EW-DE



## Highligths

- 10 Place Settings
- 3 Racks
- 7 Programmes
- E Energy Efficiency
- Freestanding 45cm
- Quick 30'
- Turbo Drying
- 9 L Water Consumption





Leaks happen but with the Aquastop you have the peace of mind that if a leak is detected the water supply is shut off to protect you and your home.



Program your dishwasher so that it starts at a time that suits you.



Keep your children safe from accidentally using the microwave with the easy to set up Child Lock.



Space at home is often at a premium but these dishwashers are just 45cm wide and still take a total of 10 place settings.
Streamlined and efficient, the way technology should be.



For those times when you only have half a load but need it done the Eco Wash allows you to select either the top or bottom half of the machine to be cleaned.



When time is of the essence this program does the dishes in 50 minutes at 60°c.

# More Features



#### Key Features

Energy Efficiency E

Quick Wash Duration (mins)

Quick 30'

Number of Programmes 7

Colour White

Cleaning Performance A

Drying Performance

Number of Place Settings 10

Number of racks 3

Dishwasher Type Freestanding 45cm

Turbo

WaterBlade & AquaGlide

N/A

Drying System

Water Consumption (L)

#### Other features

Extra Silent Option

N/A

Extra Fast Option

N/A

IntelliWash

N/A

Built-in Appliance

N/A

Advanced Inverter Motor

N/A

Graphic Displays Yes AutoDoor N/A EcoBox EcoBox MicroBan Yes Height Adjustable Upper Basket Yes Number of Mug Shelves 2 Fixed Mugshelves Foldable Racks on Upper Basket Yes Foldable Racks on Lower Basket Yes DualProWash N/A Child Lock Yes Express 50 Yes Thirty Minute Wash Yes Delay Timer Yes Super Quiet N/A Interior LED Lighting N/A Overflow and Leakage Protection Yes

EasyTray

Extra Hygiene Option

Extra Dry Option

Half Load Option



Yes

Yes

Yes

modes)

SPECDEFAULTYES (3

Number of Spray Arms	2 + extra top nozzle
Washing Cycle Indicator	Yes
Water Inlet	Cold
Noise Level (dB(A) re1 pW)	47
Adjustable Feet	Yes
Rinse-Aid Indicator	Yes
Salt Indicator	Yes
Removable Cutlery Basket	Yes
HygieneWash	N/A
Aquastop	Yes
EcoWash	Yes

Unpacked Dimensions (HxWxD) (mm)	85,0x45,0x59,8
Packed Dimensions (shrink) (HxWxD) (mm)	89,1x49,4x66,1
Product Weight Unboxed (net)(kg)	40
Product Weight Boxed (gross)(kg)	42

## Programmes

Programme 1	Prewash
	Prewas

Programme 2	Quick 30'
Programme 3	Eco 50°C
Programme 4	Express 50'
Programme 5	Delicate 40°C
Programme 6	Everyday 60°C
Programme 7	Intensive 65°C

## Code EAN

## Power, consumption, and voltage

Electrical Current (A)	10
Voltage / Frequency (V) / (Hz)	220-240 / 50
Annual Energy Consumption (Kwh)	211
Annual Water Consumption (L)	2520

## Power, Consumption&Voltage

Water Consumption (L)

